


FIG. 1

037E80" E625958

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

FIG. 2




095579.03 25/25360

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

FIG. 3A

MOBILE UNIT 103

CENTRAL SITE SERVER 107



007280" 25/25950

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

FIG. 3B

MOBILE UNIT 103

CENTRAL SITE SERVER 107

316. USER PRESSES 'MENU' KEY ON KEYPAD 413

INCOMING CONTENT:
GOES TO SPEAKER
& DTMF RECEIVER

317. MOBILE UNIT SENDS
'RETURN TO MENU'
TONE TO CENTRAL SITE
SERVER

318. HIDDEN TONE SIGNALS
'RETURN TO MENU'
PHASE

319. ACKNOWLEDGE

320. LOCAL DTMF:
CONNECTED TO
SPEAKER
MICROPHONE:
CONNECTED TO RF
MODULATOR
POSITION REPORTING:
DISABLED

321. MENU OF OPTIONS

322. USER SELECTIONS
FOLLOWED BY
'MENU' TONE

323. STORE
SELECTIONS

324. HIDDEN TONE SIGNALS
'END OF RETURN TO
MENU' PHASE

325. INCOMING CONTENT:
GOES TO SPEAKER
ONLY
LOCAL DTMF:
ISOLATED FROM
SPEAKER
MICROPHONE:
DISCONNECTED
FROM RF
MODULATOR
POSITION REPORTING:
RESUMED

326. GOTO 310

327. TERMINATE CONNECTION
IF USER TERMINATES
PHONE CALL

001230"062550




FIG. 4

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		




FIG. 5


807E20" 26/25960

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

FIG. 6A

MOBILE UNIT 103

CENTRAL SITE SERVER 107




000000" 26/25580

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

FIG. 6B

MOBILE UNIT 103

CENTRAL SITE SERVER 107



OFFICE 267-2550

337E20" 25/229968




FIG. 7

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

001E00" 20/200000

107




FIG. 8